

Model 501-7

**Extra stability kit
Montagebeslag for ekstra stabilitet**

Loosen 2 screws
Løsn 2 skruer



Insert 1 or 2 pieces of stabilizers
between the ball bearing slide and
the outer frame part in each side.
Tighten the 2 screws again.

Indsæt 1 eller 2 stabilitets plader
mellem kugleføringen og den ydre
del af løftesøjlen i begge sider.
Spænd de 2 skruer igen.

